



## BSIAB2 (Brown Sound In A Box 2) Modifications

*Version 2011November09*

*Copyright 2011 JD Sleep*

*Permission refused for posting/serving this file from any site other than [www.generalguitargadgets.com](http://www.generalguitargadgets.com)*

*Trademarks are property of their owners*

### More Bass in Tone

1. Completely Remove R8 from the PCB. This changes the "Tone Stack" to give more bass response. Do not jumper R8 just completely remove it from the circuit.
2. Solder tack a 0.22uF film capacitor across R15. So, you end up with a 0.22uF capacitor parallel to the R15 resistor.

### More Control on the Tone

Add a "Contour" control to the Tone Stack. The wiring diagram is listed on the project page. Replace R7 with a 5k6 resistor and a 100k potentiometer as shown in the wiring diagram for this mod.

*Want to contribute? If you are happy to share your modification information with other builders, contact us at [info@generalguitargadgets.com](mailto:info@generalguitargadgets.com). If the modifications pass our review we will add it to this file for all to enjoy!*