# True-Bypass, No LED Wiring Diagram

DPDT Switch, True Bypass.  This is the standard true bypass wiring.  This wiring scheme is used in lots and lots of stompboxes.